



dBbox3

the manual
version 4 firmware





Introduction - version 4 firmware

The dBbox3 is an evolution of our original dBbox designed primarily for use by sound and audio installation engineers. The unit is fitted with a powerful digital signal processor and separate microcontroller providing huge flexibility for future firmware updates. The unit allows monitoring, metering and generation of both stereo analogue and AES/EBU audio from a pocket sized unit. The dBbox3 includes a simple five button menu interface to make any test as simple as possible. With the dBbox3 you can listen to and meter AES/EBU at many sample rates, analogue line and microphone level signals with or without phantom power. The unit can analyse sample rate, bits, status word and errors. It can send tone at various levels and frequencies, send microphone input to analogue line or AES/EBU output at 48kHz or 96kHz, test phantom power, test MIDI transmit and receive, read and generate linear timecode, generate up to 80mS of delay and it even has a built in torch.

dBbox2 to dBbox3

Several 'under the bonnet' hardware changes have been made on the transition from dBbox2 to dBbox3.

The unit now has a more efficient power supply for longer battery life. There is also an auto switch off system. The accuracy of the test timecode generator has been improved and the cable tester now also tests the XLR earth wire. Improvements have been made to the MIDI circuitry and we have added a LED 'torch'. We have increased the loudspeaker volume and other improvements have been made for more flexibility with future firmware updates.

Some general information

The battery symbol on the top right of the display shows if you have enough battery power for the current function. A solid block is a full battery. The dBbox3 has an intelligent battery management system that switches off all electronics not in use for a particular test. Different functions use varying amounts of power, generating phantom from a 9 volt battery uses a lot of power and should be avoided for extended periods unless on external power. The unit may be made to switch off automatically if not used for a selectable period of 1 to 127 minutes.

When on external power (via the mini USB connector) the battery symbol will change to USB.

Press < and > together to toggle the LCD display backlight on and off.

Inserting a jack into the ¼ inch or 3.5mm headphone socket will cut the internal loudspeaker. Press Select and the Up button for one second to switch the LED light on. Press again for one second to switch it off.

Meter scale may be selected to either PPM or VU for analogue inputs and PPM,VU, -18dBFS or -20dBFS for digital inputs.



At any point in the menu system pressing Vol- and Vol+ together will return you to the main top menu.

When the volume is adjusted a 'slider' display will appear with visual indication of the current volume setting.

Using the menu system

Any menu item without > next to it is a selection. Just highlight the required line and press 'select' to jump to the function.

Any menu item with a > next to it allows a selection of various parameters or choices. Simply scroll up or down until your selection is highlighted, then press the > key, the highlighted area will move across to the right. Press the up or down keys to scroll through your choices, all changes are instant. To return to the main menu just press either < or 'select'.

For example: to listen to a phantom powered microphone on the internal loudspeaker:

Switch on the dBbox3, you are now on the top menu. Use the up/down keys to highlight 'Input'. Press the > key to move the highlighter to the right of 'Input'. Press the up/down keys to scroll through the possibilities:

Analogue
AES BNC
AES XLR
SPDIF BNC
Off

When 'Analogue' is highlighted press either the < key or press "Select". The highlight will now move back to 'Input'. Press select. You are now in the analogue input menu. Press the down key to highlight "Gain". Press the > key and the 0dB gain setting will be highlighted. Use the up/down keys to adjust the gain setting (+70dB to -10dB in 1dB steps) . The setting will move just by 1dB then speed up if the button is held down. Now press either < or "Select".

Scroll down to "Phantom" and press the > key. Press either up or down to switch phantom on. If you have plugged a phantom mic in and put in enough gain the mic will be heard through the speaker and will be metering on the display.

To switch off the mic amp press "select" or the < key and scroll up to exit, then press "select". you will be returned to the top menu. Alternatively just press the Vol+ and Vol- keys together.

The menu system really is easier to use than it is to describe.



Audio Inputs

Access to the various facilities will be described as for example:

Input> Analogue Gain > Where analogue input is selected and we are dealing with the gain settings.

Analogue Inputs, metering and monitoring

On the analogue input page it is possible to listen to and meter mono or stereo analogue signals using PPM or VU metering (as selected in Setup) with a stereo phase meter and, for testing microphones, to apply phantom power.

Input> Analogue Gain > Gain range -10 to +70dB

Input> Analogue Phantom > Phantom power (both inputs) on or off

AES/SPDIF Inputs, metering and monitoring and analyzing

All digital inputs are essentially the same apart from the connector in use, voltage levels and impedance. They all use the same display page so will all be described together. Input metering may be 18dBFS, 20dBFS, PPM or VU and includes a stereo phase meter. The unit will auto switch sample rates in the range 32kHz to 96kHz.

Input> AES BNC

Input> AES XLR

Input> SPDIF BNC

The examples will use AES BNC.

Input> AES BNC Listen > Select to listen to left, right or both Audio channels.

Input> AES BNC Errors This lists any errors that may occur on the Digital signal. Checks are made on:

- CRC Q subcode
- CRC channel status
- Unlock
- Data validity
- Biphase encoding
- Parity

With no signal input some of these errors may still show as "OK" as there is no signal to analyse or compare.



Input> AES BNC **Errors type>** loop or sticky

When set to “Loop” any errors are continuously monitored so a brief error may not be noticed. When set to “sticky” an error once set will be continuously displayed even if the signal has recovered from the error.

Input> AES BNC **Ch.Status** Shows the channel status of the AES signal. Possible readings are:

Sample rate Sample rate is calculated directly from the incoming clock. Possible displayed values are 32kHz, 44.1kHz, 48kHz, 64kHz, 88.2kHz, 96kHz, 176.4kHz and 192kHz. Any other sample rates will be displayed as ‘???’.

Audio bits Possible readable values 16 bit, 20 bit, 24 bit.

Emphasis On or off.

Generation Original or Copy

Copyright Yes or No.

Format Possible data types PCM, IEC61937, DTS_LD, DTS_CD.

Only while reading channel status some sample rates may sound distorted through the loudspeaker or headphones as it’s necessary to switch off some synchronising functions to efficiently calculate the sample rate.

Input> AES BNC **Stat.word**

This displays the first five (and most important) bytes of the AES status word in binary format.



Audio Outputs

All available output signals are the same for analogue, AES and SPDIF signals so will be described together. Analogue signals go up to +12dBu and digital signals up to 0dBFS.

- Output> Analogue**
- Output> AES BNC**
- Output> AES XLR**
- Output> SPDIF BNC**

Audio Output Menu

- Tone** Access the tone menus
- Int.Mic** Output the built in mic.
- Noise Gen.** Output pink or white noise
- Frame Rate>** This item will only show if digital output is selected. Set to 48kHz or 96kHz as required.

These examples will use AES BNC.

- Output> AES BNC** **Tone Type>** Various types of tone output are available:
- Steady Continuous tone both channels.
- GLITS Graham's Line Ident Tone System. Used extensively for Stereo line identification by the BBC amongst others.
- EBU Cyclic break on the left channel, steady on the right.
- Sweep Tone rising in frequency from 20Hz to 20kHz. Press Vol- or Vol+ to start the sweep.
- Left Left channel only
- Right Right channel only



| | | |
|---|----------------------------|--|
| Output> AES BNC | Tone Level> | Sets the output level of the tone from -60dB to +12dB in 1dB steps. Settings will be retained in memory. |
| Output> AES BNC | Tone Frequency> | Sets the frequency of the tone in third octave steps from 50Hz to 20kHz. |
| Output> AES BNC | Tone OP listen> | Switch to 'on' to enable the internal speaker and volume control for confidence monitoring. |
| Output> AES BNC | Int.mic | Enables the user to speak to analogue or digital outputs using the built in microphone. |
| Output> AES BNC | Int.mic Gain> | Sets the internal mic gain or effectively the level on the outputs. Available settings +12dB, +6dB, 0dB, -6dB, -12dB |
| Output> AES BNC | Int.mic Limiter> | Sets the threshold of the limiter on the outputs. Possible settings +12dB, +6dB, 0dB, -6dB, -12dB |
| Output> AES BNC | Int.mic Output> | Select to left, right or both outputs. |
| Output> AES BNC | Noise Gen. | |
| Generates pink or white noise with a frequency range of 20Hz to 20kHz | | |
| Output> AES BNC | Noise Generator | Type> Set output of the noise Generator to Pink or White noise. |
| Output> AES BNC | Noise Generator | Level> Set output level of the noise generator from -60dB to +12dB in 1dB steps. Setting will be retained in memory. |



| | | | |
|---------------------------|------------------------|----------------------|---|
| Output> AES BNC | Noise Generator | Output> | Select to left, right or Both outputs. |
| Output> AES BNC | Noise Generator | OP listen> | Switch to 'on' to enable the internal speaker and volume control for confidence monitoring. |

Phantom power measurement

Phantom

Connect your phantom mic cable to Ana Out L. Phantom power will be measured on both live and neutral (XLR pins 2 and 3) with a tolerance of +- 1 volt.

Four Wire Box

4 Wire Box

This feature is analogue only.

The dBbox3 will act as a four wire box using the internal microphone and speaker or headphones. Listen to incoming audio and adjust the volume using Vol- and Vol+. Up. If the speaker is in use it will cut on talk to prevent feedback, the headphones will not.

Press the down arrow to speak on the internal mic. The microphone passes through a limiter, the threshold of this limiter is set by

Output> Analogue **Int.mic Limiter>**

Signal conversion

In/Out/FX

This page allows conversion of audio signals with the addition of a limiter, gain adjustment and equalization. Note that only 48kHz AES signals may be used in this menu.

In/Out/FX **Input>** Available inputs Analogue, AES BNC, AES XLR and SPDIF.



| | | |
|-------------------------|--------------------------|--|
| <i>In/Out/FX</i> | <i>Output></i> | Available outputs Analogue, AES BNC, AES XLR and SPDIF |
| <i>In/Out/FX</i> | <i>Gain></i> | Gain range will be +70dB to -10dB when on analogue input (to allow for microphone levels) and +12dB to -10dB when on digital inputs. |
| <i>In/Out/FX</i> | <i>Phantm></i> | Phantom power on/off. This item may only be changed in on analogue input, else it will Be forced to off. |
| <i>In/Out/FX</i> | <i>Limit></i> | Switches the limiter on or off. |
| <i>In/Out/FX</i> | <i>Lim Th></i> | Adjusts the limiter threshold. Possible settings +12dB, +6dB, 0dB, -6dB, -12dB. |
| <i>In/Out/FX</i> | <i>HF></i> | High frequency equalization. Range -12dB to +12dB in 1 dB steps. |
| <i>In/Out/FX</i> | <i>Mid></i> | Middle frequency equalization. Range -12dB to +12dB in 1 dB steps. Centered around 1kHz. |
| <i>In/Out/FX</i> | <i>Low></i> | Low frequency equalization. Range -12dB to +12dB in 1 dB steps. |

MIDI

The MIDI menu is broken down into two selections, MIDI analyse and MIDI notes.

MIDI Analyse

This is used to analyse incoming MIDI data and will display the MIDI channel number (where applicable) , the MIDI message and the associated data.

The mode or type is shown as a text description (ie. 'system common') and as data in blocked characters. MIDI signals may be passed through the unit so MIDI may be in use while being analysed.



- MIDI Analyse Format>** Selects MIDI data to be displayed in hexadecimal or decimal.
- MIDI Analyse Clear>** Clears the screen
- MIDI Analyse Oneshot>** When the cursor is put over 'oneshot' the word will change to 'Waiting'. When the next MIDI message is received it will displayed on the screen and all following messages will be ignored. This is useful for analysing a single message when many messages may be passing through. Press 'select' to clear the screen and wait for the next message.

MIDI Notes

The MIDI notes page incorporates a MIDI transmitter and a MIDI receiver, they may be used at the same time.

- MIDI Notes Channel>** Selects the MIDI channel to transmit the note on. Range 1-16.
- MIDI Notes Note>** Selects the MIDI note number to be transmitted. Range 0-127.
- MIDI Notes Veloc.>** Selects the velocity of the transmitted MIDI note. Range 0-127.
- MIDI Notes Send On** Highlight this and press select to transmit your MIDI note with 'note on' information.
- MIDI Notes Send Off** Highlight this and press select to transmit your MIDI note with 'note off' information.
- MIDI Notes Clr RX** This will clear all data from the MIDI RX Display ready for the next received data.

The MIDI RX area will display MIDI channel, note number and velocity of the last received MIDI data. It is also displayed at the bottom of the page in hexadecimal for analysis purposes.



More

The more menu enables selection of the Timecode reader, Timecode generator, Tone Loop, 2Wire listen and Cable Test.

More/Read Timecode

This option reads linear timecode at 24, 25, 29.97 and 30 frames per second using the Ana in L XLR. The timecode is also output through the Ana XLR outputs so it may be used as an 'in line' check. If the drop frame flag is set in the timecode stream then 'DF' will be displayed at the end of the time readout. The reader will resolve timecode down to a level of -30dBu. The timecode may be monitored and metered, the meter will follow whichever type has been selected in 'setup/ ana meter'. (PPM or VU).

More Read Timecode Freeze Press select while this is highlighted to freeze the timecode display. When selected it will change to read. Select again to restart the display

More Read Timecode nnFPS This selects the frame rate range for the reader. Set to 25FPS for 24 or 25FPS or 30FPS for 29.97 (dropframe) or 30FPS.

More/Generate Timecode

This generates test linear timecode at 24, 25, 29.97 (dropframe) and 30 frames per second using the Ana out L XLR. Level is set at 0dBu.

More Generate Timecode Start Press select while this is highlighted to start timecode generation. Generation will start at the time displayed. When started the display will change to 'Freeze'. Select again to stop the timecode. Timecode continues to be generated at the frozen time.

More Generate Timecode Clear This will set the timecode generated to 00:00:00:00.



More Generate Timecode Set Starts the timecode at a pre-defined time. Select 'Set' then the cursor will move to tens of hours. Press the up or down key to adjust tens of hours. Then press the right arrow to move to hour units and adjust using up/down. The cursor may be moved between columns as required with the left and right keys. When adjusted as required press 'select' to return to the menu functions.

More Generate Timecode FPS Set to generate at 24/25/29.97 or 30 frames per second.

Note: The timecode generator is not crystal locked and may lose or gain a few seconds per hour, it is intended as a test not a reference generator, it may be however also be useful for jam syncing several devices.

More/Tone Loop

Tone loop enables output tone output and audio input at the same time. Input and output signals may be selected to analogue or AES formats with adjustable input and output gain and adjustable frequency. This is useful for testing operation of external equipment, checking frequency response etc. Analogue signals are output on the left channel output XLR and input on the left channel input XLR. AES signals are output on both AES channels and input may be selected to monitor/meter left or right channels.

More ToneLoop Input Available inputs Analogue, AES BNC L, AES BNC R, AES XLR L, AES XLR R, SPDIF BNC L, SPDIF BNC R.

More ToneLoop Output Available Outputs Analogue, AES BNC, AES XLR, SPDIF BNC.

More ToneLoop IPgain Input gain adjustable -10dBm to +70dBm on analogue input or -10dBm to +12dBm on AES inputs.

More ToneLoop Freq Frequency adjustable in third octave steps 50Hz to 20kHz.

More ToneLoop OPgain Output level adjustable from -60dBm to +12dBm.



More/ 2W Listen

This will listen to and meter unbalanced audio inputs on pins 2 and 3 of the left XLR input with pin 1 as common earth. It is not suitable for use with Clearcom beltpacks due to their call signaling system.

- | | |
|------------------------------|---|
| More 2W listen Listen | Select to listen to channel 1 (XLR pin 2), Channel 2 (XLR pin 3) or both. |
| More 2W listen Gain | Adjust input level gain from -10dB to +12dB |

More/ Cable Test

Test XLR, BNC and MIDI DIN cables. XLR will indicate open circuit, phase reversed and in phase connections on XLR pins 1, 2 and 3. BNC will test the centre (live) conductor only. MIDI DIN will check MIDI connections (DIN pins 4 and 5). The clicking noise heard when using this function is a relay disconnecting the XLR earth in order to test it.

More/More (select even more)

More/More/Delay

This provides a delay of up to 80mS in mono or 40mS in stereo.
If AES is used please note this feature will only function correctly at 48kHz.

- | | |
|-----------------------------------|--|
| More More Delay Input> | Select analogue, AES BNC, AES XLR or SPDIF BNC input(s). |
| More More Delay Output> | Select analogue, AES BNC, AES XLR or SPDIF BNC output(s) |
| More More Delay Delay> | Select up to 80mS delay in mono or 40mS in stereo. If set above 40mS and mode is then set to stereo this will default to (and display) 40mS. |
| More More Delay Mode> | Set to mono or stereo delay |
| More More Delay OP Mon> | Switch on to monitor the delayed signal. Use the volume controls to adjust level. |



More/More/Setup

This page enables the user to set metering preferences, adjust the display contrast and to personalize the dBbox3 so when switched on it will display, for example, your name and phone number.

- | | |
|-----------------------------------|---|
| More Setup Ana_meter> | Select all analogue metering to PPM or VU Meter scale and ballistics. |
| More Setup AES_meter> | Select both AES BNC and AES XLR inputs to PPM, VU, -18dBFS or -20dBFS Metering. |
| More Setup SPDIF_meter> | Select SPDIF input to PPM, VU, -18dBFS or -20dBFS Metering. |
| More Setup Contrast> | Adjust the contrast of the display. Range 0 (lowest) to 9 (highest). |
| More Setup Headphones> | Set the headphone output to mono or stereo. |

More/Setup/More Setup

- | | |
|---|---|
| More More Setup MoreSetup PPM top scale> | Select top scale of PPM to UK, dB or EBU. |
| More More Setup MoreSetup Spkr ana limit> | Switches the speaker limiter on and off. Select to off for more level on the speaker but note that the battery may be working very hard, especially on loud audio peaks which may have undesirable effects on the function of the display or the box itself. Recommended setting is on. |



Personalise

More Setup MoreSetup Personalise

This allows you to set up a two line message, with up to 40 characters on the display which

will be displayed when the dBbox3 is switched on. A typical use of this would be a “this unit belongs to” message. It is important to note that when this facility has been used it cannot be changed without return of the dBbox3 to CTP Systems. The personalise message may also be disabled if you are concerned someone may find it amusing to put an alternative message on your dBbox3!

If a personalise message is entered when switched on the dBbox3 will display the message along with ‘Press any key’ to start the unit.

How to personalise the dBbox3

Setup Personalise

A warning message will come up stating this cannot be undone. Press any key. Read again, then press any key.

You are now presented with a choice of:

- | | |
|----------------|------------------------------------|
| Exit | No setup, back to the normal menu. |
| Disable | Disable the personalise facility |
| Start | Start the personalization process. |

Use the left/right keys to select as required, then press “Select”.

If you select “disable” you will be presented with “You have selected to delete this facility, Are you sure?”

Using the left/right key select:

- | | |
|------------|--|
| No | No setup, not disabled, back to the normal menu. |
| Yes | This facility will be disabled and cannot be used in the future. |

If you selected “Start” you will have a blank screen with just a down arrow. This is the current character position. Either press up or down to select a character or move the arrow to the right to start in the next position and so on. The left and right keys move the arrow either way and it wraps round to the second line. It’s worth planning out 2 lines of 20 character positions before proceeding.



The left key will move the arrow back the other way. If you wish to erase a character just put in a space (next character up from small "z"). Do not press "Select" until you have finished your message. You will then be presented with a screen:

Exit This will exit the personalise routine with no change
Save This will save your message and it will be displayed on power up from now on.

Auto SwitchOff

More Setup MoreSetup Auto Switchoff Auto switch off can be set over a range of off to 127 minutes. If the unit is on and the time elapses with no buttons on the dBbox3 having been pressed then the unit will automatically switch to a very low current virtually off mode. To switch it back on select the power switch to off, wait half a second and then switch it on again. When the timer is counting down it will be restarted whenever a button is pressed on the unit so, for example, if it is set to 30 minutes and after 15 minutes a button is pressed then the timer will set back to 30 minutes.

LED Torch

Press Select and the Up button for one second to switch the LED light on. Press Select and the Up button again for one second to switch it off.

USB

The dBbox3 has a mini USB connector for external power and to update the firmware. Any USB outlet may be used to power the device, a computer or even an iPhone mains adaptor using the correct mini USB lead.

Firmware updates will be available on our website, please see:

<http://www.ctpsystems.co.uk/support.html>

All new firmware may be downloaded from here along with instructions and drivers.



Levels

All dB references in this manual relate to the following:

The dBbox3 '0dB' output level is 0dBu, that is it generates 0.775 volts into a 10k ohm load, the most common input impedance these days. Into a 600 ohm load it will be approximately 0.3dB lower. The dBbox3 balanced analogue output impedance is 75 ohms. Inevitably the dBbox3 will sometimes be plugged into a source with phantom power or something unpleasant on the line and the unit must be able to protect

itself. This protection comes at a price which includes a slightly higher output impedance in order to overcome these possibilities, hence the variation.

If you have any firmware problems with your dBbox3 or you spot any incorrect details in our manual please let us know so we can correct. Thank you.

| | |
|-------------------------------|---|
| Specifications. | Analogue and AES/SPDIF combined. |
| Input metering – Ref. 0dBu | accurate to within ± 0.2 dB or one display segment. 125Hz – 20kHz accurate to within ± 1 dB or one display segment. 50Hz – 20kHz |
| Output levels – Ref. 0dBu | accurate to within ± 0.2 dB 50Hz – 15kHz accurate to within ± 0.4 dB 50Hz – 20kHz Normally within ± 0.1 dB at 1kHz. |

Phantom power measurement- ± 1 volt.

dBbox2 and dBbox3 firmware is the intellectual property and copyright of CTP Systems in the UK ©2014-2021